


# everlasting **Flameless** C A N D L E

## INSTRUCTIONS

1. Use the On - Off switch on bottom of the candle to turn LEDs to ON Flicker position or the OFF position. (see A)
2. Switch to "off" when not in use.
3. To replace battery, install 2 new "CR2032" battery into the bottom battery compartment. Make sure that the battery polarity (+) faces out as indicated. (see B)

LED bulbs last a minimum of 100,000 hours.



**Mark Feldstein & Associates, inc.**

Maumee, Ohio 43537 • [www.markfeldstein.com](http://www.markfeldstein.com)